



North Zone Communications Committee

TRAINING TOPIC EPH, GPH and GPH Command Series Pocket Cards

June 2007

Attached you will find quick reference instructions for the operation of the Bendix King GPH and GPH Command series portable radios. The individual cards are designed to be cut out and laminated for a quick pocket reference.

Bendix King GPH-CMD

How to build a Command Group.

Turn off both scan switches before doing the following:

- To add channels to CMND Group, while in any group and on any channel, press the [*] key. Program up to 20 channels into the CMND Group.
- To select the CMND Group, press [#] key twice.
- To delete a CMND channel, while in CMND Group, press [*] key once.
- To delete entire CMND Group, press and hold [*] key until screen displays "CMND EMPTY".

Updated May 27, 2007, Captain Fred Schoenheit, NCF

Bendix King GPH-CMD

Turn off both scan switches before doing the following:

- To change groups, press [#] followed by the 2 digit group number and then press [ENT] key once.
- To add current channel to scan list, press the [ENT] key once.
- To remove current channel from scan list, press the [CLR] key once.
- To add current channel as priority scan channel, press the [PRI] key once. Individual radios may be configured differently
- To change tones, turn repeater switch to "RPT", enter the 2 digit tone number.
- To lock an unlocked keypad, press [FCN] key once.
- To unlock a locked keypad, press [FCN] key once.

Bendix King GPH

Turn off both scan switches before doing the following:

- To change groups, press [#] followed by the 2 digit group number and then press [ENT] key once.
- To add current channel to scan list, press the [ENT] key once.
- To remove current channel from scan list, press the [CLR] key once.
- To add current channel as priority scan channel, press the [PRI] key once. Individual radios may be configured differently
- To change tones, turn repeater switch to "RPT", enter the 2 digit tone number.
- To lock an unlocked keypad, press [FCN] key once.
- To unlock a locked keypad, press [FCN] key once.